



ZERA

Instructions for use

MT30

Portable reference meter

Keep for reference

9. February 2023



Table of contents

1	General	4
	Declaration of conformity	5
	About these Instructions for use	6
2	Safety	7
	Intended use	8
	Essential safety regulations	9
	Requirements for personnel and personal protective equipment	10
3	Design and function of the reference meter	11
	Contents of the case	12
	The MT30 reference meter	14
	Controls and indicators	15
	Connection panel	17
	Technical data	18
4	Design and operation of the user interface	20
	The software interface	21
	The status bar	22
	The function bars	23
5	Taking test measurements	24
	Switching on the reference meter and preparing for testing	25
	General procedure for a test measurement	27
	Attaching the scanning head to the meter	30
	Entering the meter constant	31
	Error Measurement using a scanning head	32
	Error Measurement without scanning head	34
	Performing a W-register test (energy register)	37
	Performing a P-register test (power register)	38
6	Connection diagrams	39
	Single-phase 2-wire meter connected directly	40
	Three-phase 3-wire meter connected directly	42
	Three-phase 3-wire meter with current and voltage transformer	44
	Three-phase 4-wire meter connected directly	46
	Three-phase 4-wire meter with current transformer	48
	Three-phase 4-wire meter with current and voltage transformer	50
7	The horizontal function bar of the reference meter in detail	52
	The functions in outline	53
	The measurement ranges	55
	The measuring modes	56
8	The functions of the reference meter	57
	Actual values	58
	Vector	61
	Curve	64
	Harmonics	65
	Error measurement	67
	W-register test (energy register)	69
	P-register test (power register)	70
	Selective – optional	71
	Saved Data	72

Source (ext.) - optional	74
Dosage (ext.) – optional	77
Settings	79
Settings (2)	81
Ratio	82
The Save Data subfunction	84
9 Calculation of derived values	86
Calculating the voltage	87
Calculating the current	88
Power for the 4-wire measurement	89
Power for the three-phase 3-wire measurement	90
Phase angles	91
Accuracy test	92
10 Troubleshooting and routine maintenance	93
Cleaning and routine maintenance	94
Battery use	95
Potential problems arising from the hardware	96
Potential problems arising from use	97
Warranty, Service, Disposal	99
Index	100

General

Contents

In this Chapter

Page

Declaration of conformity

5

About these Instructions for use

6

Declaration of conformity

Manufacturer	ZERA GmbH Humboldtstraße 2a D-53639 Königswinter
Validity of Declaration of conformity	The company ZERA GmbH hereby declares under sole responsibility that the product described below is in conformity with the fundamental requirements of the Directives listed below: <ul style="list-style-type: none">• Product description: Portable reference meter• Model: Moving Test MT30
Declaration of conformity with Directives	The manufacturer declares that the reference meter described above is in conformity with the following directives: <ul style="list-style-type: none">• 2014/30/EU (Electromagnetic Compatibility)• 2014/35/EU (Low Voltage Directive)
Standards compliance	The reference meter described above complies with the requirements in the following European standards: <ul style="list-style-type: none">• DIN EN 61010-1• DIN EN 61000-4-2• DIN EN 61000-4-3• DIN EN 61000-4-4• DIN EN 61000-4-5• DIN EN 61000-4-6• DIN EN 61000-4-8• DIN EN 61000-4-11• DIN EN 55011


About these Instructions for use

Issued by ZERA GmbH
Humboldtstraße 2a
D-53639 Königswinter




Tel +49 2244 9277-0
Email info@zera.de
Web www.zera.de

Validity and purpose These Instructions for use apply to the MT30 reference meter, firmware version 6.25.

The Instructions for use contain the information needed for safe and correct working practices when testing installations and meters.

Target readership  The Instructions for use are intended solely for trained electricians who are **additionally qualified to work with live voltages**.

Conventions used for hazard notices The hazard notices are categorized according to the following hazard levels:

Hazard level	Consequence	Likelihood
 DANGER	Death / serious injury (irreversible)	Immediate hazard
 WARNING	Death / serious injury (irreversible)	Potential hazard
 CAUTION	Minor injury (reversible)	Potential hazard
NOTICE	Damage to property	Potential hazard

Safety

Summary

The Safety chapter contains information that is essential to read and follow before using the reference meter.

Contents

In this Chapter

Page

Intended use

8

Essential safety regulations

9

Requirements for personnel and personal protective equipment

10

Intended use

Intended use

The MT30 is a portable reference meter. It is used for on-site testing under mains load of various types of electricity meter

- Ferraris meters
- Electronic meters

The reference meter can be used for:

- Testing meter installations in a single-phase two-wire, three-phase three-wire or three-phase four-wire system
- Checking the meter's energy register and power register
- Measuring active, reactive and apparent power
- 4-quadrant measurements
- Measuring frequency, phase angle and power factor
- Analysing voltage and current harmonics up to the 40th harmonic
- Measuring the total harmonic distortion
- Vectorial view of the measured values
- Oscilloscope function for waveform sampling
- Rotating field indication

The reference meter must be used within the limits specified in the Technical Data

Restrictions on use

The reference meter must not be used for measurements that lie outside the ranges specified in the Technical Data.

Essential safety regulations



Persons who should read these regulations	These regulations are intended for any person who works with the reference meter.
Purpose of these regulations	These regulations are intended to ensure that any person working with the reference meter has a thorough understanding of the associated hazards and safety precautions and heeds the safety instructions given in the Instructions for use. You risk injury and even death if you do not follow these instructions, and you may also cause damage to property.
Using the Instructions for use	<p>Follow the instructions below:</p> <ul style="list-style-type: none"> • Read carefully the Safety chapter and those chapters relating to your activity. You must have understood the information contained in these chapters. • Always keep the Instructions for use available for reference. • Pass on the Instructions for use with the reference meter.
Using the instrument safely	<p>Follow the instructions below:</p> <ul style="list-style-type: none"> • Only those persons who meet the requirements stipulated in these Instructions for use are allowed to use the reference meter. • Employ the reference meter solely for the intended use. Never use the reference meter under any circumstances for other purposes, even if these may seem perfectly normal. • Take all the safety precautions specified in these Instructions for use. Use in particular the personal protective equipment specified • Always ensure your hands and footwear are dry and the floor is dry before using the instrument. • Do not make any modifications to the reference meter. In particular, you are not allowed to modify or disable any safety devices.
Ensuring the reference meter is in good working order	<p>Follow the rules below:</p> <ul style="list-style-type: none"> • Only use the reference meter if the case and all the accessories are in perfect condition. • Check all cables for breaks or for cracks in the insulation before use. Immediately replace any cables showing signs of damage. • Make sure that <ul style="list-style-type: none"> • you always use insulated safety voltage pins/cables for more than 40 V. • you never use unprotected metal pins or banana plugs. • Make sure that all connections are plugged in properly. Loose connections can cause arcing, overheating or short-circuits and may damage the equipment and/or associated devices.
Requirements for the environment in which the equipment is used	<p>The <i>Technical Data</i> on page 18 contains the specification for the equipment environment.</p> <p>Restrictions on use:</p> <ul style="list-style-type: none"> • The equipment must be operated solely in enclosed spaces and/or with suitable protection against rain and water spray/splash and excessive heat, e. g. from direct sunlight. • The environment of use must be dry.

Requirements for personnel and personal protective equipment

Requirements for personnel	Measurements using the reference meter must be carried out solely by an electrician who is additionally trained and qualified in working with live voltages.
Who is an electrician?	An electrician is someone who, based on his/her technical training, knowledge and experience and familiarity with the relevant regulations, can assess the work assigned to him/her and recognize potential hazards.
Personal protective equipment	Personal protective equipment is required when working with live voltages. National regulations relating to safety at work specify the requirements for personal protective equipment.

Design and function of the reference meter

Summary

This chapter introduces you to the reference meter.

Contents

In this Chapter

Page

Contents of the case

12

The MT30 reference meter

14

Controls and indicators

15

Connection panel

17

Technical data

18

MT30 – Design and function of the reference meter

Contents of the case

Details

The reference meter is always supplied in a special case. The contents of the case will vary depending on the purchase order.

Photo of the case

The reference meter inside the aluminium case alongside typical accessories




Delivery note

A delivery note is included with each case. The delivery note tells you what the case contained when shipped. Check against the delivery note that the case contains all the parts listed.

MT30 – Design and function of the reference meter

Basic kit



Elements of the basic kit

No.	Name
1	Reference meter
2	AC current clamps
3	Scanning head (various types available, with separate Instructions for use)
4	Scanning-head mount
5	Power supply unit (mains adapter)
6	Four coloured laboratory leads

A calibration certificate is always included with every reference meter.


MT30 – Design and function of the reference meter

The MT30 reference meter

The MT30

The MT30 is a reference meter. The reference meter is used to check meter installations (single-phase two-wire, three-phase three-wire and three-phase four-wire systems).

Overview of the reference meter



Design of the reference meter

No.	Details
1	Connection panel
2	Operating panel
3	Ventilation
4	Type plate
5	Belt fastening (4x)
6	Reset button
7	Battery compartment

MT30 – Design and function of the reference meter

Controls and indicators

Front view of the reference meter




Controls and indicators

No.	Name	Function
1	Screen	Displays all the functions and measured values (6.4" monochrome backlit LCD screen)
2	Function keys	Used to select the functions displayed on the screen
3	Keypad and cursor control	<ul style="list-style-type: none"> • Alphanumeric input • Cursor control • Input confirmation

MT30 – Design and function of the reference meter

The control panel




The control buttons

No.	Name	Function
1	ON/OFF button Function key	<ul style="list-style-type: none"> Switch reference meter on or off Used to select the functions displayed on the screen
2	Function keys	Used to select the functions displayed on the screen
3	Cursor up	Move cursor upwards
4	Enter	Confirm input
5	Cursor right	Move cursor to the right
6	Cursor down	Move cursor downwards
7	Cursor left	Move cursor to the left
8	Clear	Delete the character currently indicated by the cursor
9	Numeric keypad	Used for entering numbers and letters (press repeatedly)
10	Special characters	Used for entering special characters ., +, -, ?, !

Connection panel

Connection panel



Purpose of the connectors and LEDs

No.	Name	Details
1	DC IN 16V	Connection for mains adapter <ul style="list-style-type: none"> • Power supply for the reference meter • Charges the built-in battery
2	f OUT	BNC connector for connecting to a reference meter. The frequency of the signal is proportional to the power.
3	SC	"RJ10" 4P4C connector for scanning head for pulse acquisition
4	UL1	Voltage connection for line phase 1, max. 300 V CAT III
	UL2	Voltage connection for line phase 2, max. 300 V CAT III
	UL3	Voltage connection for line phase 3, max. 300 V CAT III
	UN	Voltage connection for neutral, maximum 300 V CAT III
5	-	Indexing hole for the quick-connect voltage connector to prevent wrong polarity.
6	LED P (Power)	Power status LED
	LED R (Ready)	Ready status LED
7	CT	25-pin connector for: <ul style="list-style-type: none"> • AC current clamps • Temperature sensor
8	RS-232	RS-232 interface D-Sub DE-9 Port for connecting a PC Port for connecting an external source Port for connecting a serial printer
9	LED CHARGE	Status LED showing level of battery charge

Charge status LED

LED	Details
Permanently on	Instrument being powered from the mains adapter Internal battery is fully charged
Flashing slowly	Instrument being powered from the mains adapter Internal battery is being charged
Flashing rapidly	Instrument being powered from the mains adapter Internal battery is faulty; must be replaced immediately
Off	Instrument under battery power

Technical data

General

Date	Value
Power supply	16 V DC $\pm 3\%$, 2.5 A
Power consumption	~ 20 VA
Rechargeable battery operation : operating time	~ 1 h
Rechargeable battery operation : recharging time	~ 3 h
At cells with different charge up to max.30 h	
Temperature range, operation	-15 ... +50 °C
Temperature range, storage	-15 ... +65 °C
Relative humidity (not condensing)	max. 95 %
Dimensions (L×W×H)	190 × 190 × 80 mm
Weight	~ 1.6 kg
Max. height above sea level	2000 m
External power supply unit	Type: Mascot 9921 (90 ... 264 V / 47 ... 63 Hz / max 0.9 A)

Safety

Date	Value
IP class according to DIN EN 60529	IP40
Declaration of conformity	CE conform
Overvoltage category voltage measurement Option CAT IV 300V	CAT III 300 V
Overvoltage category, current measurement (MT3430)	CAT III 30 V

Reference meter

Date	Value
Measuring modes	1-ph 2 WA / WR / WAP
Depending on the selected option	3-ph 3 WA / WR / WRCA / WRCB / WAP 3-ph 4 WA / WAb / WR / WRb / WRC / WAP / WAPb
Fundamental frequency	15 ... 70 Hz
Bandwidth	3000 Hz
Sampling	16 bit 504 samples/period
Accuracy class for measuring of power / energy	0.2
Rotary field indication	yes
Angle measurement accuracy From 30 V ... 300 V (45 ... 65 Hz) From 500 mA ... 120 A (45 ... 65 Hz)	< 0.1°
Frequency measurement deviation	± 0.01 Hz

Voltage Measurement

Date	Value
Number of voltage channels	3
Voltage measurement	10 ... 300 V
Voltage range(s)	250 V
Usage of ranges	10 ... 120 % @ 15 ...70 Hz 2 ... 120 % @ 50 Hz

MT30 – Design and function of the reference meter

Date	Value
Input impedance of voltage channels (@ range)	264.5 kΩ @ 250 V
Voltage measurement accuracy From 30 V ... 300 V (45 ... 65 Hz) Related to the read value at optimum range selection	< 0.05 % @ 30 ... 300 V
Voltage measurement temperature drift From 30 V ... 300 V (45 ... 65 Hz)	< 15×10^{-6} / K
Voltage measurement stability Stability over 1 hour (every minute one measurement with $t_i = 60$ s)	< 50×10^{-6}
Voltage measurement long term stability Stability over 1 year (every month one measurement over one hour) From 30 V ... 300 V (45 ... 65 Hz)	< 100×10^{-6} / Year
Voltage measurement linearity	< 100×10^{-6}

Current measurement using AC current clamps MT3430

Date	Value
Current measurement	5 mA ... 120 A
Current range(s)	100 A, 50 A, 10 A, 5 A, 1 A, 500 mA, 100 mA, 50 mA
Usage of ranges	10 % ... 120 %
Current measurement accuracy Related to the read value at optimum range selection	< 0.15 % @ 500 mA ... 120 A < 0.3 % @ 100 mA ... 500 mA
Current measurement temperature drift From 500 mA ... 120 A (45 ... 65 Hz)	< 50×10^{-6} / K
Current measurement stability Stability over 1 hour (every minute one measurement with $t_i = 60$ s) From 500 mA ... 120 A (45 ... 65 Hz)	< 150×10^{-6}
Current measurement long term stability Stability over 1 year (every month one measurement over one hour) From 500 mA ... 120 A (45 ... 65 Hz)	< 600×10^{-6} / Year
Clamp for cables up to \emptyset	12 mm

Power measurement (@MT3430)

Date	Value
Power/energy measurement accuracy From 30 V ... 300 V (45 ... 65 Hz) From 500 mA ... 120 A (45 ... 65 Hz) Related to the read value at optimum range selection Related of apparent power	< 0.2 %
Power/energy measurement temperature drift From 30 V ... 300 V (45 ... 65 Hz) From 500 mA ... 120 A (45 ... 65 Hz)	< 65×10^{-6}
Power/energy measurement stability Stability over 1 hour (every minute one measurement with $t_i = 60$ s)	< 200×10^{-6}
Power/energy measurement long term stability Stability over 1 year (every month one measurement over one hour)	< 700×10^{-6} / Year

4 Design and operation of the user interface

Summary This chapter describes the general layout of the user interface. Details of the screens displayed for the various functions are given in the Chapter *Functions provided by the reference meter* on page 57

Contents	In this Chapter	Page
	The software interface	21
	The status bar	22
	The function bars	23


The software interface

Details

The software interface displays all the data and possible functions. The software is operated using the buttons arranged around the screen edge. Values can be entered using the numeric keys.

Layout of the software interface

The figure shows the essential layout of the software interface. The contents in the different areas of the screen vary depending on the function selected.



Areas of the software interface and their purpose


No.	Details	Function
1	Status bar	<ul style="list-style-type: none"> Shows general system information such as system time and battery status Shows the selected function and the measurement presets
2	Display area	<ul style="list-style-type: none"> Shows the measurement data in various display modes
3	Vertical function bar	Shows subfunctions for selection using function keys
4	Horizontal function bar	Shows various functions for selection using function keys

The status bar

Details

The status bar shows the currently selected function, the measurement range and the measurement mode.

Layout of the status bar



Areas of the status bar and their purpose

No.	Details	Function
1	Date and time	Shows the date and time
2	Function	Shows the selected function
3	Voltage measuring range UR	Shows the voltage measurement range
4	Current measurement range IR	Shows the current measurement range
5	Battery indicator	Shows the power supply status
6	Mode MM	Shows the selected measurement mode

What the battery indicator means


Display	Details
	Powered from the mains adapter
	Operation under battery power
	The status bar indicates the battery charge level.

The function bars

Purpose of the horizontal function bar

The horizontal function bar is used to select the function, measurement range and mode. It can also be used for actuating core functions of the reference meter such as starting and stopping the measurement.

Layout of the horizontal function bar



Functions of the horizontal function bar

No.	Name	Details
1	Func.	Select function
2	–	unassigned
3	IR	Select current measurement range
4	MM	Select measurement mode
	Print	Print measurement data
	Load	Load settings for external source
5	Start	<ul style="list-style-type: none"> Start measurement Display actual values for the measurement in progress
	Save	<ul style="list-style-type: none"> Save measurement data Save settings for external source
	Delete	Delete all measurement data
	On	Enable external source
6	Stop	<ul style="list-style-type: none"> Stop measurement Display actual values for the stopped measurement
	Back	Back to function
	Off	Disable external source

Purpose of the vertical function bar

The vertical function bar is used to open the subfunctions of the functions ('Func.'). Details of the subfunctions are given with the associated functions.

Taking test measurements

Summary

The Taking test measurements chapter describes the test procedure for measuring certain values. Measurement results that can be displayed without any specific procedure are described directly in the chapter *The functions provided by the reference meter* on page 57.

Contents


In this Chapter	Page
Switching on the reference meter and preparing for testing	25
General procedure for a test measurement	27
Attaching the scanning head to the meter	30
Entering the meter constant	31
Error Measurement using a scanning head	32
Error Measurement without scanning head	34
Performing a W-register test (energy register)	37
Performing a P-register test (power register)	38

Switching on the reference meter and preparing for testing


Introduction

Certain preliminary settings must be made in order to perform a test measurement. These presets are retained for all measurements until changed again by the operator.





Switching on

Step	Procedure	
1	Press the ON/OFF button for about 5 seconds. Result: the screen comes on and the Start-up screen is displayed.	 ON / OFF

Switching off





Step	Procedure	
1	Press the ON/OFF button for about 5 seconds. Result: the screen switches off.	 ON / OFF

Selecting the system language

Step	Procedure	
1	Select the 'Settings' function.	
2	Select the subfunction 'Select the system language' .	
3	Select the language you require.	 
4	Confirm your selection.	

Selecting the phase angle calculation under the 'Norm' entry

The 'Select angle calculation' subfunction under the 'Norm' entry defines how phase angles are measured, calculated and displayed in the vector diagram; see 'Settings' on page 79. The names of the two options derive from past standards. This documentation uses the terms 'IEC 387' and 'DIN 410' to distinguish between the two options. Selecting 'DIN 410' will define U1 as the reference value, while selecting 'IEC 387' defines I1 as the reference value.

Step	Procedure	
1	Select the 'Settings' function.	
2	Select the 'Select angle calculation' subfunction.	
3	Choose the option you require: <ul style="list-style-type: none"> • IEC 387 or • DIN 410 	 
4	Confirm your selection.	

MT30 – Taking test measurements

Measuring under battery power


The test instrument can optionally be powered from rechargeable batteries rather than the mains adapter. Battery operation is not suitable for measurements that take a long time, which may be the case for the Error Measurement and Register tests.

General procedure for a test measurement

Measuring principle



In a meter test, the energy consumption measured (metered) by a meter is compared with the result from the reference meter. In order to be able to make the comparison, the reference meter must measure the current and voltage in exactly the same way as the meter itself, and compare these readings with the meter result. The meter result from the meter is signalled by pulses from an LED or the number of revolutions of a rotor disc. This signal can be detected by a scanning head and transmitted to the reference meter.

Typical connection diagram



MT30 – Taking test measurements

General procedure for connecting the reference meter to a device under test

Step	Description	
1	Connect the AC current clamps to the CT input of the reference meter.	
2	Connect the voltage cables to the inputs U_1 , U_2 , U_3 , U_N of the reference meter.	
3	Connect the reference meter to the mains supply: <ul style="list-style-type: none"> • Connect the mains adapter to the mains supply. • Connect the mains adapter to the DC IN 16V input of the reference meter. • Switch on the reference meter. Result: the reference meter powers up. <ul style="list-style-type: none"> • Wait until the reference meter is ready for use. 	
4	Make the following settings at the reference meter: <ul style="list-style-type: none"> • Select the current measurement range; see <i>The Measurement ranges</i> on page 55 • Select a suitable measuring mode; see <i>The measuring modes</i> on page 56 	
5	Connect the voltage cables to the device under test: <ul style="list-style-type: none"> • first U_N • then U_1, U_2, U_3 	
6	Clamp the AC current clamps around the cables L1, L2 and L3 that supply the current. Make sure that the AC current clamps are fully closed and sit in the correct direction. Measurement results will be incorrect if the AC current clamps are not fully closed (air gap) or if the current is flowing in the wrong direction.	
7	Attach the scanning head to the meter; see <i>Attaching the scanning head to the meter</i> on page 30.	
8	Connect the scanning head cable to the SC input on the reference meter and then to the scanning head. Result: the LED on the scanning head flashes in time with the LED on the meter or the mark on the rotor disc. If this is not the case, realign the scanning head.	
9	Check the settings at the reference meter for the current measurement range, and correct the range if necessary.	
	Video tutorial: 	
10	Enter the meter constant in the 'Error measurement' function; see <i>Entering the meter constant</i> on page 31.	
11	For CT operated meters, enter their associated ratio in the 'Ratio' function; see 'Ratio' on page 82.	
12	Perform the measurements you require.	
13	Save your test results.	

MT30 – Taking test measurements

General procedure for disconnecting the reference meter from the device under test

Step	Description
1	Disconnect the scanning head cable from the scanning head and the reference meter.
2	Remove the scanning head.
3	Disconnect the voltage cables from the device under test: <ul style="list-style-type: none"> • U₁, U₂, U₃ first • U_N last
4	Remove the AC current clamps from the device under test.
5	Switch off the reference meter and disconnect it from the mains adapter.
6	Disconnect the voltage cables from the reference meter.
7	Remove the AC current clamps from the reference meter.


Attaching the scanning head to the meter

Further details on scanning heads

ZERA offers a range of scanning heads and mounts, each of which has its own Instructions for use. These dedicated Instructions for use contain details of the scanning heads and how they are fitted to the meter.

Illustration as an example

The following picture illustrates a scanning head with mount by way of example:



Design and operation

No.	Name	Details
1	Scanning head	<p>The scanning head detects the signal from the meter.</p> <ul style="list-style-type: none"> Scanning heads come in various designs. They can be attached to the meter using mounts, magnets or suction pads, for instance. The scanning head is connected to the reference meter via the scanning-head input connector.
2	Mount	<p>The mount is used to fit the scanning head to the meter.</p> <ul style="list-style-type: none"> Mounts come in various designs depending on the scanning head. The mounts can be fastened to the meter using clamps or even belts, e. g. for round-shaped meter enclosures.


Entering the meter constant

The meter constant

The meter constant indicates the number of LED pulses given per kWh for an electronic meter, or the number of revolutions made per kWh for a mechanical meter. The meter constant is written on the meter type plate or can be found in the meter documentation. The meter constant must be saved in the reference meter before the actual meter testing starts.

Screenshot of entering the meter constant

The meter constant is entered in the 'Error measurement' function.



Entering the meter constant

Step	Procedure
1	Open the subfunction for entering the meter constant (4).
2	Enter the meter constant in the input field (1). A multiplier (2) is needed for values ≥ 1000000 .
3	Select a multiplier from the list box (2). Exp-5 (0.00001) ... 1 ... Exp+5 (100000)
4	Select the units from the list box (3).

Units for the meter constant

Function	Details
I/kWh	Pulses per kilowatt-hour
I/kvarh	Pulses per kilovar-hour for reactive power
I/kVAh	Pulses per kiloVolt-Ampere hour for apparent power
Wh/I	Watt-hours per pulse
varh/I	Var-hours per pulse for reactive power
VAh/I	Volt-Ampere hours per pulse for apparent power

Error Measurement using a scanning head


Aim The purpose of the error measurement using a scanning head is to measure the percentage error of the device under test.

Method The reference meter uses the scanning head to detect the amount of energy (number of pulses) metered by the device under test, and compares this with the amount of energy measured by the reference meter. The percentage error is calculated from the comparison.

Requirements The following requirements must be met before performing a test:

- The reference meter has been prepared for the test; see *General procedure for a test measurement* on page 27.
- The meter constant has been entered; see *Entering the meter constant* on page 31.
- The scanning head has been connected; see *Attaching the scanning head to the meter* on page 30
- The 'Error Measurement' function is open; see *Error measurement* on page 67.

Screenshot of entering the pulse source The pulse source is entered in the 'Error measurement' function.




Entering data for the pulse source

Step	Procedure
1	Open the subfunction for entering the pulses to be counted (4).
2	Select the correct pulse source from the list box (1): <ul style="list-style-type: none"> • SC
3	Enter the number of pulses (2) to be counted for the measurement (number of revolutions for Ferraris disc meters). <ul style="list-style-type: none"> • A multiplier (3) is needed for values ≥ 1000000.
4	Select a suitable multiplier between 1 and Exp+5 (100000) from the list box (3). Result: <ul style="list-style-type: none"> • You have finished entering the data for the pulse source. • The button (4) returns to its normal appearance.

MT30 – Taking test measurements

Taking measurements

Step	Procedure	
1	Watch the LED on the scanning head to check it is emitting enough pulses in a suitable time period to avoid the test taking too long.	
2	Start the test. Result: <ul style="list-style-type: none"> • The measured energy is displayed. • The progress bar indicates how far the measurement has progressed. • An error value is displayed once the first measurement has finished. • The test continues to take further measurements. The unit displays the error for the most recent measurement. 	Start
3	Stop the test. Result: <ul style="list-style-type: none"> • The reference meter displays the error for the most recent measurement. • Continuous measurements are stopped. 	Stop
4	Save the measurement.	

Accuracy of the measurement


The accuracy of the measurement depends on fitting the scanning head precisely; for details, refer to the specific instructions for the scanning head used.

Error Measurement without scanning head

- Aim** The error measurement without scanning head is intended for measuring the percentage error of the device under test when a scanning head cannot be used.
- Method** The operator counts the amount of energy (pulses) signalled by the device under test. The reference meter simultaneously measures the amount of energy consumed. The operator starts and stops the meter-tester measurement manually.
- The reference meter compares the energy values metered by the device under test with the amount measured by the reference meter. The percentage error is calculated from the comparison.
- Requirements** The following requirements must be met before performing a test:
- The amount of energy supplied to the meter under test is so small that the operator can easily see and count the rotations of the rotor disc on Ferraris meters or the frequency of the flashing LED pulse.
 - The reference meter has been prepared for the test; see *General procedure for a test measurement* on page 31.
 - The meter constant has been entered; see *Entering the meter constant* on page 31.
 - The 'Error Measurement' function is open; see *Error measurement* on page 67.

Screenshot of entering the pulse source

The pulse source is entered in the 'Error measurement' function.



Entering data for the pulse source




Step	Procedure
1	Open the subfunction for entering the pulses to be counted (4).
2	Select the correct pulse source from the list box (1): <ul style="list-style-type: none"> • SC MAN or St/St
3	Enter the number of pulses (2) to be counted for the measurement.
4	Select the multiplier 1 from the list box (3). Result: <ul style="list-style-type: none"> • You have finished entering the data for the pulse source. • The button (4) returns to its normal appearance.

MT30 – Taking test measurements

Taking measurements using 'TK MAN' pulse source (manual pushbutton)

For the test using the manual pushbutton, the operator must count the signals until they reach the number entered under Pulses. At precisely this instant, the operator uses the manual pushbutton to confirm that the set number of pulses has been reached.

Follow these steps to perform the test:




Step	Procedure	
1	Watch the LED on the meter or watch the meter disc to check it is emitting enough signals in a suitable time period to avoid the test taking too long.	
2	Press the 'Start' function key to make ready for the measurement.	
3	Start the measurement when there is a pulse (pulse zero) from the LED or meter disc by pressing the manual pushbutton. Result: • The measurement starts running.	
4	Count the number of pulses after the start pulse according to the set number of pulses. Do not touch the manual pushbutton while counting the pulses. Result: • The measured energy is displayed.	
5	Press the manual pushbutton once you have reached the last pulse to be counted, given by the set number of pulses. Result: • The progress bar flashes. • The error from the measurement is displayed. • The next measurement begins; the measured energy is reset to 0. You can repeat this step as often as you wish.	
6	Stop the test. Result: • The reference meter displays the error for the performed measurement. • Continuous measurements are stopped.	
7	Save the measurement.	

MT30 – Taking test measurements

Taking measurements using Start and Stop

For the test using 'Start' / 'Stop', the operator must count the signals until they reach the number entered under Pulses. At this precisely this instant, the operator uses 'Stop' to confirm that the set number of pulses has been reached.

Follow these steps to perform the test:

Step	Procedure
1	Watch the LED on the meter or watch the meter disc to check it is emitting enough signals in a suitable time period to avoid the test taking too long.
2	Start the measurement when there is a pulse (pulse zero) from the LED or meter disc by pressing the 'Start' function key. 
	Result: <ul style="list-style-type: none"> The measured energy is displayed.
3	Count the number of pulses after the start pulse according to the set number of pulses.
4	Press the 'Stop' function key to stop the measurement once you have reached the last pulse to be counted, given by the set number of pulses. 
	Result: <ul style="list-style-type: none"> The unit displays the error for the most recent measurement.
5	If possible, perform more than one test.
6	Save the measurement. 

Accuracy of the measurement

The accuracy of the measurement in both measuring methods depends on the user. The user must count the pulses and press the manual pushbutton or 'Stop' at the right moment.

Performing a W-register test (energy register)





Aim The W-register test is designed to test the accuracy of a W-register (energy register).

Method The operator reads the initial value in the W-register from the device under test and enters this reading in the reference meter. The reference meter then measures the energy consumption over a certain period of time. The operator stops the measurement, reads the final value in the W-register from the device under test and also enters this reading in the reference meter.

The percentage error is calculated from the comparison of the entered readings with the value measured by the reference meter.

- Requirements**
- The reference meter has been prepared for the test; see *General procedure for a test measurement* on page 27.
 - The required current range has been selected; see *The measurement ranges* on page 55.
 - The required mode has been selected; see *The measuring modes* on page 56.
 - The 'W-register test' function is open; see *W-register test (energy register)* on page 69.

Taking measurements Follow these steps to perform the test:

Step	Procedure	
1	Open the function for entering the initial value from the energy register.	
2	Enter the initial value and select the register units.	
3	Start the test.	
4	Stop the test.	
5	Open the function for entering the final value from the energy register.	
6	Enter the final value and select the register units. Result: The reference meter displays the calculated error.	

Accuracy of the measurement The accuracy of the measurement depends on the user. The user must read and enter the values at the start and stop time correctly and precisely.

MT30 – Taking test measurements

Performing a P-register test (power register)


Aim The P-register test is designed to test the accuracy of a P-register (power register).

Method The operator reads the initial value in the P-register from the device under test and enters this reading in the reference meter. The reference meter then measures the power over a certain period of time. The operator stops the measurement, reads the final value in the P-register from the device under test and also enters this reading in the reference meter.





The percentage error is calculated from the comparison of the entered readings with the value measured by the reference meter.

- Requirements**
- The reference meter has been prepared for the test; see *General procedure for a test measurement* on page 27.
 - The required current range has been selected; see *The measurement ranges* on page 55.
 - The required mode has been selected; see *The measuring modes* on page 56.
 - The 'P-register test' function is open; see *P-register test (power register)* on page 70.

Entering the time for the P-register test You have the option to change the settings for the measurement time.

Step	Procedure	
1	Open the setting for the measurement time.	
2	Manual time measurement <ul style="list-style-type: none"> • Skip the step for entering the measurement time • Select 'Off'. Automatic time measurement <ul style="list-style-type: none"> • Enter a measurement time • Select 'On'. 	

Performing a P-register test

Step	Procedure	
1	Open the function for entering the initial value from the power register.	
2	Enter the initial value and select the register units.	
3	Start the test.	
4	Stop the test (only if automatic time measurement is 'Off')	
5	Open the function for entering the final value from the power register.	
6	Enter the final value and select the register units. Result: The reference meter displays the calculated error.	

Accuracy of the measurement

The accuracy of the measurement depends on the user. The user must read and enter the values at the start and stop time correctly and precisely.

Connection diagrams

Summary

The connection diagrams show how the reference meter must be connected for different types of meter connection. They state the measuring modes available for each connection type and what settings are needed for the measuring mode.

Contents

In this Chapter

Page

Single-phase 2-wire meter connected directly	40
Three-phase 3-wire meter connected directly	42
Three-phase 3-wire meter with current and voltage transformer	44
Three-phase 4-wire meter connected directly	46
Three-phase 4-wire meter with current transformer	48
Three-phase 4-wire meter with current and voltage transformer	50

Single-phase 2-wire meter connected directly


Required data

- Meter constant; see *Entering the meter constant* on page 31

Measuring modes available

2WA, 2WR, 2WAP, see *The measuring modes* on page 56

Connection diagram



MT30 – Connection diagrams

Rules

The following rules must be observed when connecting the clamps:

- AC current clamps come in different designs, for insulated lines or for uninsulated lines. The AC current clamps for insulated lines must be used only on insulated lines; see the Instructions for use for the particular AC current clamps.
- The 25-pin connector for the AC current clamps must not be removed from the test instrument while the AC current clamps are still clamped around a line or the test instrument is still on.
- Clamp the AC current clamp around the cable of the line that leads to the current input terminal. The arrow on the current clamp points towards the meter.

Also refer to the *General procedure for a test measurement* on page 27.

Three-phase 3-wire meter connected directly


Required data

- Meter constant; see *Entering the meter constant* on page 31
- Enter the ratio 1:1 for the voltage transformer (VT) and current transformer (CT); see *Settings* on page 79

Measuring modes available

3WA, 3WR, 3WAP, see *The measuring modes* on page 56

Connection diagram



MT30 – Connection diagrams

Rules

The following rules must be observed when connecting the clamps:

- AC current clamps come in different designs, for insulated lines or for uninsulated lines. The AC current clamps for insulated lines must be used only on insulated lines; see the Instructions for use for the particular AC current clamps.
- The 25-pin connector for the AC current clamps must not be removed from the test instrument while the AC current clamps are still clamped around a line or the test instrument is still on.
- Clamp the AC current clamp around the cable of the line that leads to the current input terminal. The arrow on the current clamp points towards the meter.

Also refer to the *General procedure for a test measurement* on page 27.

Interpreting the measurement results

With this type of connection, the following readings are not shown: current for L2, $\angle UI$, $\angle IU$, λ , S for all lines.

Three-phase 3-wire meter with current and voltage transformer


Required data

- Meter constant; see *Entering the meter constant* on page 31
- Ratio for voltage transformer (VT); see *Settings* on page 79
- Ratio for current transformer (CT); see *Settings* on page 79

Measuring modes available

3WA, 3WR, 3WAP, see *The measuring modes* on page 56

Connection diagram



Do not open the secondary side of the current transformer

⚠ DANGER

High voltage generated by opening the secondary side of the current transformer while the transformer is still electrically live.

If the secondary side of the current transformer is opened while current is still flowing in the primary side, i.e. the primary side is still live, a hazardous high voltage may be induced in the secondary side.

- Never under any circumstances open the secondary side of a current transformer while the transformer is electrically live.

MT30 – Connection diagrams

Rules

The following rules must be observed when connecting the clamps:

- AC current clamps come in different designs, for insulated lines or for uninsulated lines. The AC current clamps for insulated lines must be used only on insulated lines; see the Instructions for use for the particular AC current clamps.
- The 25-pin connector for the AC current clamps must not be removed from the test instrument while the AC current clamps are still clamped around a line or the test instrument is still on.
- Clamp the AC current clamp around the cable of the line that leads to the current input terminal. The arrow on the current clamp points towards the meter.

Also refer to the *General procedure for a test measurement* on page 27.

Interpreting the measurement results

With this type of connection, the following readings are not shown: current for L2, $\angle UI$; $\angle IU$ λ , S, for all lines.

Three-phase 4-wire meter connected directly


Required data

- Meter constant; see *Entering the meter constant* on page 31
- Enter the ratio 1:1 for the voltage transformer (VT) and current transformer (CT); see *Settings* on page 79

Measuring modes available

4WA, 4WAb, 4WR, 4WRb, 4WAP, 4WAPb, see *The measuring modes* on page 56

Connection diagram



MT30 – Connection diagrams

Ratio for instrument transformer

Since an instrument transformer is not used in the circuit, set the ratio for instrument transformer to 1 : 1.

- 'Settings': ratio
 - Voltage transformer U: $1 \times 1 \rightarrow 1 \times 1$
 - Current transformer I: $1 \rightarrow 1$

or

- 'Settings (2)': ratio for the meter constant is disabled for Actual values (and Register test) and Meter constant (error measurement)

Rules

The following rules must be observed when connecting the clamps:

- AC current clamps come in different designs, for insulated lines or for uninsulated lines. The AC current clamps for insulated lines must be used only on insulated lines; see the Instructions for use for the particular AC current clamps.
- The 25-pin connector for the AC current clamps must not be removed from the test instrument while the AC current clamps are still clamped around a line or the test instrument is still on.
- Clamp the AC current clamp around the cable of the line that leads to the current input terminal. The arrow on the current clamp points towards the meter.

Also refer to the *General procedure for a test measurement* on page 27.

Three-phase 4-wire meter with current transformer


Required data

- Meter constant; see *Entering the meter constant* on page 31
- 1:1 ratio for voltage transformer (VT); see *Settings* on page 79
- Ratio for current transformer (CT); see *Settings* on page 79

Measuring modes available

4WA, 4WAb, 4WR, 4WRb, see *The measuring modes* on page 56

Connection diagram



MT30 – Connection diagrams

Do not open the secondary side of the current transformer



High voltage generated by opening the secondary side of the current transformer while the transformer is still electrically live.

If the secondary side of the current transformer is opened while current is still flowing in the primary side, i.e. the primary side is still live, a hazardous high voltage may be induced in the secondary side.

- Never under any circumstances open the secondary side of a current transformer while the transformer is electrically live.

Rules

The following rules must be observed when connecting the clamps:

- AC current clamps come in different designs, for insulated lines or for uninsulated lines. The AC current clamps for insulated lines must be used only on insulated lines; see the Instructions for use for the particular AC current clamps.
- The 25-pin connector for the AC current clamps must not be removed from the test instrument while the AC current clamps are still clamped around a line or the test instrument is still on.
- Clamp the AC current clamp around the cable of the line that leads to the current input terminal. The arrow on the current clamp points towards the meter.

Also refer to the *General procedure for a test measurement* on page 27.

Three-phase 4-wire meter with current and voltage transformer


Required data

- Meter constant; see *Entering the meter constant* on page 31
- Ratio for voltage transformer (VT); see *Settings* on page 79
- Ratio for current transformer (CT); see *Settings* on page 79

Measuring modes available

4WA, 4WAb, 4WR, 4WRb, see *The measuring modes* on page 56

Connection diagram



Do not open the secondary side of the current transformer

⚠ DANGER

High voltage generated by opening the secondary side of the current transformer while the transformer is still electrically live.

If the secondary side of the current transformer is opened while current is still flowing in the primary side, i.e. the primary side is still live, a hazardous high voltage may be induced in the secondary side.

- Never under any circumstances open the secondary side of a current transformer while the transformer is electrically live.

Rules

The following rules must be observed when connecting the clamps:

- AC current clamps come in different designs, for insulated lines or for uninsulated lines. The AC current clamps for insulated lines must be used only on insulated lines; see the Instructions for use for the particular AC current clamps.
- The 25-pin connector for the AC current clamps must not be removed from the test instrument while the AC current clamps are still clamped around a line or the test instrument is still on.
- Clamp the AC current clamp around the cable of the line that leads to the current input terminal. The arrow on the current clamp points towards the meter.

Also refer to the *General procedure for a test measurement* on page 27.

The horizontal function bar of the reference meter in detail

Summary

The horizontal function bar is used to select the function, measurement range and mode. It can also be used for actuating core functions of the reference meter such as starting and stopping the measurement.

Contents

In this Chapter

Page

The functions in outline

53

The measurement ranges

55

The measuring modes

56

MT30 – The horizontal function bar of the reference meter in detail


The functions in outline

Function groups

The functions can be grouped into the following areas:

Function group	Function
Measured values display	<ul style="list-style-type: none"> Actual Values Vector Curve Harmonics Selective - optional
Running tests	<ul style="list-style-type: none"> Error Measurement W-Registertest P-Registertest
Settings	<ul style="list-style-type: none"> Settings Settings(2) Ratio
Data management	<ul style="list-style-type: none"> Saved Data
Controlling an external device	<ul style="list-style-type: none"> Source (ext.) - optional Dosage (ext.) - optional

The functions



The functions in outline

Function	Description	Subfunctions
Actual Values	Displays the actual measured values as a table	<ul style="list-style-type: none"> U, I, $\angle U$, $\angle UI$; $\angle IU$, λ, P, Q, S Distortion factor Total power values
Vector	Displays the actual values as a vector diagram	<ul style="list-style-type: none"> Normal Delta mode 3-line mode
Curve	Displays the actual values as a waveform	<ul style="list-style-type: none"> Selection of required UL and IL channels
Harmonics	Displays the harmonics of the actual values referred to the fundamental frequency	<ul style="list-style-type: none"> As a table up to the 40th harmonic As a bar graph up to the 40th harmonic
Error Measurement	Measures the error of a meter	<ul style="list-style-type: none"> Entering the meter constants pulse source number of pulses for measurement
P-Registertest	Tests the power register of a meter	<ul style="list-style-type: none"> Entering register readings

MT30 – The horizontal function bar of the reference meter in detail


Function	Description	Subfunctions
W-Registertest	Tests the energy register of a meter	<ul style="list-style-type: none"> • Entering register readings
Selective	Displays the active, reactive and apparent power components of the first 40 harmonics	<ul style="list-style-type: none"> • Selection of L1, L2, L3 • Selection of harmonics to be displayed
Saved Data	Displays the saved data	<ul style="list-style-type: none"> • Navigation around the saved data
Source (ext.)	Controls an external ZERA source	<ul style="list-style-type: none"> • Selecting the Symmetry/ Frequency • Entering voltage, current and phase angle • Activating individual phases • Saving and managing settings
Dosage (ext.)	Controls the "dose" of energy supplied from an external ZERA source	<ul style="list-style-type: none"> • Actuating dosage mode • Entering the dosage energy
Settings	Used for specifying global settings that apply to all the measurements	<ul style="list-style-type: none"> • System language • Phase angle • Control of the reference meter
Settings(2)	Used for specifying additional global settings that apply to all the measurements	<ul style="list-style-type: none"> • System time • Calculation method for the apparent power • Printer
Ratio	Can be used to enter the transformer ratios of input-side current and/or voltage transformers.	<ul style="list-style-type: none"> • Ratio for input-side voltage and current transformers • Ratio for high-current transformer of AC current clamps • Conversion of actual values

MT30 – The horizontal function bar of the reference meter in detail

The measurement ranges

Measurement ranges

The voltage measurement range 'UR' is always 250 V. The current measurement ranges can be selected. It is essential to choose the correct measurement range to obtain an accurate measurement result.



What the voltage measurement range means (IR:)

Current measurement range	Details
C100 A to C50 mA	Measurement range set manually using AC current clamp
Auto	Measurement range set automatically

Selecting the setting

With the 'Auto' setting, the reference meter seeks the appropriate measurement range itself.


If the power consumption varies sharply at the measurement point, we recommend selecting the measurement range manually. Any strong variation in the power consumption when 'Auto' is set will result in incorrect measurement results, e.g. in the error measurement and power measurement.

MT30 – The horizontal function bar of the reference meter in detail

The measuring modes

Mode (MM)

The measuring mode required depends on the way the meter under test is connected. Selecting the wrong measuring mode will produce incorrect results.



What the measuring modes mean

Mode	Details
2WA	1-phase, 2-Wire, Active power
2WR	1-phase, 2-Wire, Reactive power
2WAP	1-phase, 2-Wire, APparent power
4WA	3-phase, 4-Wire, Active power
4WAb	3-phase, 4-Wire, Active power of fundamental harmonic
4WR	3-phase, 4-Wire, Reactive power, true
4WRC	3-phase, 4-Wire, Reactive power with phase-shift Circuit
4WAP	3-phase, 4-Wire, APparent power
3WA	3-phase, 3-Wire, Active power
3WR	3-phase, 3-Wire, Reactive power, true
3WRCA	3-phase, 3-Wire, Reactive power with phase-shift Circuit A
3WRCB	3-phase, 3-Wire, Reactive power with phase-shift Circuit B
3WAP	3-phase, 3-Wire, APparent power

Optional measuring modes

Mode	Details
4WRb	3-phase, 4-Wire, Reactive power of fundamental harmonic
4WAPb	3-phase, 4-Wire, APparent power of fundamental harmonic

Special features of the 3-phase, 3-wire measurements

For this measuring mode, the total apparent power (S_{Σ}) is always geometric.

$$S_{\Sigma} = \sqrt{P_{\Sigma}^2 + Q_{\Sigma}^2}$$

The functions of the reference meter

Summary

The reference meter provides many different functions and measurement ranges, each available for a choice of measuring modes.

Contents

In this Chapter





Page

Actual values	58
Vector	61
Curve	64
Harmonics	65
Error measurement	67
W-register test (energy register)	69
P-register test (power register)	70
Selective – optional	71
Saved Data	72
Source (ext.) - optional	74
Dosage (ext.) – optional	77
Settings	79
Settings (2)	81
Ratio	82
The Save Data subfunction	84

MT30 – The functions of the reference meter

Actual values

- Description** The 'Actual Values' function displays the currently measured values as a table.
- Application** The table view of the actual values provides a rapid overview for error analysis. The actual values measurement helps to assess the condition of the mains supply and the meter installation, for instance no voltage, no current, incorrect current polarity, symmetry and asymmetry, etc.
- Subfunctions** The 'Actual Values' function contains the following subfunctions:

Function	Details
	<ul style="list-style-type: none"> Main measured values displayed in table form Selecting the phase angle calculation under the 'Norm' entry: IEC 387 or DIN 410
	Harmonic distortion factor displayed in table form
	Total values for power displayed in table form
	See <i>Save Data subfunction</i> on page 84


Meaning of the 'Norm' selection for the phase angle display

The choice made under the 'Norm' entry affects how values are displayed:

Options	Details
IEC 387	<ul style="list-style-type: none"> Current vectors are fixed, voltage vectors are variable Reference value I₁, displayed horizontally $\varphi(I_1)$ is always 0 (in 3 O'clock position) Positive angle is anticlockwise
DIN 410	<ul style="list-style-type: none"> Voltage vectors are fixed, current vectors are variable Reference value U₁, displayed vertically $\varphi(U_1)$ is always 0 (in 12 O'clock position) Positive angle is clockwise

Measured values displayed as a table

The standard for the phase-angle representation must be defined first when opening this view.

05.01.2018 12:00		UR:	IR:	
Actual values		250 V	C100 A	4WA
Norm:	IEC 387			
	L1	L2	L3	
Upn	236.79	230.65	232.84	V
Upp	404.80	401.39	406.75	V
I	9,958	9,962	10,335	A
∠U	59.65	299.66	179.67	°
∠IU	59.65	59.84	59.97	°
λ	0.4954	0.5007	0.4768	
P	1,168	1,150	1,150	kW
Q	1,977	1,968	1,988	kVar
S	2,358	2,298	2,411	kVA

Func.

IR

MM

Start

Stop

MT30 – The functions of the reference meter

What the values in the table mean

Some of the measured values displayed are calculated values; see *Calculation of derived values* on page 86.

Measured value	Details	Source	Resolution
Upn	Effective value of the voltage between phase and neutral for each phase	measured	0.01 V
Upp	Effective value of the voltage between the phases 1–2, 2–3, 3–1	calculated	0.01 V
I	Effective value of the current for each phase	measured	100, 50 A: 0.001 A 10, 5, 1 A: 0.0001 A 500 mA: 0.01 mA
$\angle U$	Phase angle φ of the voltage, with zero phase given by the chosen standard	measured	0.01°
$\angle UI$; $\angle IU$	Phase angle between voltage and current (DIN 410) or current and voltage (IEC 387). The values are the same in both standards.	measured	0.01°
λ	Power factor • Active power measurement: $\lambda = P/S = \cos(\angle UI)$ • Reactive power measurement: $\lambda = Q/S = \sin(\angle UI)$	calculated	0.0001
P	Active power	calculated	0.01 W 0.001 kW
Q	Reactive power	calculated	0.01 var 0.001 kvar
S	Apparent power	calculated	0.01 VA 0.001 kVA

Harmonic distortion factor displayed in table form


	L1	L2	L3
Ud	23.91	7.44	15.58 %
Id	4.37	8.53	26.45 %

What the measured distortion factors mean

Measured value	Details	Source	Resolution
Ud	Distortion factor for the voltage of one phase	calculated	0.01 %
Id	Distortion factor for the current in one phase	calculated	0.01 %

MT30 – The functions of the reference meter

Total values in table form



What the total values in the table mean

Measured value	Details	Source	Resolution
ΣP	Sum of the active powers for all the phases	calculated	0.01 W 0.001 kW
ΣQ	Sum of the reactive powers for all the phases	calculated	0.01 var 0.001 kvar
ΣS	Sum of the apparent powers for all the phases Setting for the calculation method: <i>Settings (2)</i> on page 81	calculated	0.01 VA 0.001 kVA
$\Sigma \lambda$	Total power factor	calculated	0.0001
F	Frequency	measured	0.01 Hz
PS	Direction of rotating field <ul style="list-style-type: none"> • 123: ∪ clockwise rotation • 132: ∩ anticlockwise rotation 	calculated	
T	Temperature The temperature display is only possible when a temperature sensor is connected. The screen displays "???" if a sensor is not connected.	measured	0.01 °C

MT30 – The functions of the reference meter





Vector

Description The 'Vector' function displays the actual values as a vector diagram. Certain representations are only relevant to certain measuring modes.

Application Die vector diagram helps to locate circuit faults:

- Incorrect connections
 - Wrong terminal and incorrect rotating field
 - Polarity (e.g. K-L swapped over)
- Short-circuits
 - Inside the meter (e.g. transport damage)
 - At the current transformer (e.g. jumper not removed)
 - Damage to insulation (e.g. through overheating / overloading)
- Open-circuits
 - In the instrumentation of the meter (e.g. transport damage)
 - Voltage tab not closed
 - Broken wire
 - Contact fault

Subfunctions The 'Vector' function contains the following subfunctions:

Function	Details
	<ul style="list-style-type: none"> • Measured values displayed in vector form • Selecting the phase angle calculation under the 'Norm' entry: IEC 387 or DIN 410 • Shows voltage between line and neutral (Star) • Useful for the following measuring modes: <ul style="list-style-type: none"> • 4WA
	<ul style="list-style-type: none"> • Measured values displayed in vector diagram in Delta mode • Voltage between two lines • Useful for the following measuring modes: <ul style="list-style-type: none"> • 4WA
	<p>Measured values displayed in vector form in 3-wire mode</p> <ul style="list-style-type: none"> • Useful for the following measuring modes: <ul style="list-style-type: none"> • 3WA
	See <i>Save Data subfunction</i> on page 84

Meaning of the 'Norm' selection for the vector diagram


The choice made under the 'Norm' entry affects how values are displayed:

Options	Details
IEC 387	<ul style="list-style-type: none"> • Current vectors are fixed, voltage vectors are variable • Reference value I₁, displayed horizontally • $\varphi(I_1)$ is always 0 (in 3 O'clock position) • Positive angle is anticlockwise
DIN 410	<ul style="list-style-type: none"> • Voltage vectors are fixed, current vectors are variable • Reference value U₁, displayed vertically • $\varphi(U_1)$ is always 0 (in 12 O'clock position) • Positive angle is clockwise

MT30 – The functions of the reference meter

Measured values displayed in vector form in 4WA mode

Options 'IEC 387': I1 to the right is defined as $\varphi = 0$.




Options 'DIN 410': U1 vertically upwards is defined as $\varphi = 0$.

What the values in the vector diagram mean

Parameter	Details
U1, U2, U3	Voltage between neutral and line 1, 2, 3
I1, I2, I3	Current in phase 1, 2, 3

Measured values displayed in vector diagram in Delta mode




What the values in the vector diagram mean in Delta mode

Parameter	Details
U12	U1 – U2 as a vector
U23	U2 – U3 as a vector
U31	U3 – U1 as a vector
I1, I2, I3	Current in phase 1, 2, 3

MT30 – The functions of the reference meter

Measured values displayed in vector diagram in 3-wire mode



What the values in the vector diagram mean in 3-wire mode

Parameter	Details
U12	U1 – U2 as a vector
U32	U3 – U2 as a vector
I1	Current in phase 1
I3	Current in phase 3


MT30 – The functions of the reference meter

Curve

Description

The 'Curve' function displays the actual values as a waveform.

Display





Description of parameters

Parameter	Details
CH-1	Measured value from channel 1
CH-2	Measured value from channel 2
Vertical	Measured value in % of measurement range
Horizontal	Phase angle in °

Subfunctions

The 'Curve' function contains the following subfunctions:

Function	Details
	<ul style="list-style-type: none"> Select the measured value for channel CH-1: UL1, UL2, UL3, IL1, IL2, IL3 Select the measured value for channel CH-2: UL1, UL2, UL3, IL1, IL2, IL3
	See <i>Save Data subfunction</i> on page 84

MT30 – The functions of the reference meter





Harmonics

Description The 'Harmonics' function displays the actual values of the harmonics referred to the fundamental harmonic.

Application The 'Harmonics' function indicates whether there are harmonic distortions in the current or voltage.

Measurements on currents of less than 50 mA give inaccurate results. This is because the AC current clamps inherently produce high harmonic components when $I \leq 50$ mA.

Subfunctions The 'Harmonics' function contains the following subfunctions:

Function	Details
	Select the measured value for CH: <ul style="list-style-type: none"> UL1, UL2, UL3, IL1, IL2, IL3 Measured value and angle displayed in table form
	Switch display to the next 10 harmonics: 0...10→10...20→20...30→30...40→0...10→...
	<ul style="list-style-type: none"> Open the bar graph view Close the bar graph view
	See <i>Save Data subfunction</i> on page 84



Displayed as a table

05.01.2018 12:00
UR: IR:

Harmonics
250 V C100 A 4WA

CH-1: THD: 0.34 %

N	Amount	Angle
0	0.06 %	0.00 °
1	100.00 %	0.00 °
2	0.21 %	115.54 °
3	0.15 %	79.99 °
4	0.05 %	74.35 °
5	0.18 %	20.73 °
6	0.02 %	4.47 °
7	0.07 %	1.65 °
8	0.03 %	16.39 °
9	0.01 %	37.00 °
10	0.02 %	14.98 °

SEL
HARM
← N →




Func. IR MM Start Stop

MT30 – The functions of the reference meter

What the values in the table mean

Parameter	Details
CH	Selected channel; default setting: UL1
THD	Total harmonic distortion up to the 40th harmonic in %
N	Number of the harmonic. 11 harmonics are displayed at once.
Amount	The ratio of the amplitudes of the Nth harmonic and fundamental in %
Angle	Magnitude of the phase angle between the Nth harmonic and the fundamental in °
0..	DC component
1	Fundamental: mains frequency f
2.	$2 \times f$
3	$3 \times f$
etc.	etc.

Displayed as a bar graph



What the values in the bar graph mean

Parameter	Details
CH	Selected channel
THD	Total harmonic distortion in %
Vertical	The ratio of the amplitudes of the Nth harmonic and fundamental in % on logarithmic scale
Horizontal	Number of the harmonic

Error measurement


Description

The 'Error measurement' function measures the error of a meter. The error measurement compares the energy measured by the reference meter with the energy measured by the meter. The energy measured by the meter is transferred to the reference meter by a pulse sensor or by the user counting the pulses. When the measurement has finished, the error of the device under test is displayed as a %.

The following sections explain how to perform the error measurement:

- *Settings* on page 79
- *Error measurement under manual control* on page 34

Display






Description of the display

Parameter	Details
Constant:	Meter constant, multiplier and units
Pulses:	<ul style="list-style-type: none"> • Pulse source • Number of pulses to be counted • Multiplier
Status	<ul style="list-style-type: none"> • The bar shows how far the measurement has progressed • E: states the energy measured by the reference meter during the measurement <p>If the device under test is reading accurately, the amount of energy given by the pulse count will equal the amount of energy measured. For the case given in the example above, this would be:</p> $E = \frac{500 \times 1 \text{ I}}{10000 \times 1 \frac{\text{I}}{\text{kWh}}} = 0.05 \text{ kWh}$
F:	Error for the last measurement in %

MT30 – The functions of the reference meter

Subfunctions

The 'Error measurement' function contains the following subfunctions:

Function	Details
	<ul style="list-style-type: none"> • Enter the meter constant • Select the multiplier • Select the units
	<ul style="list-style-type: none"> • Select the pulse source • Enter the number of pulses to be counted • Multiplier selection: 1, EXP+1, EXP,+2, ... Exp+5 (100000)
	See <i>Save Data subfunction</i> on page 84

Units for the meter constant

Function	Details
I/kWh	Pulses per kilowatt-hour
I/kvarh	Pulses per kilovar-hour for reactive power
I/kVAh	Pulses per kiloVolt-Ampere hour for apparent power
Wh/I	Watt-hours per pulse
varh/I	Var-hours per pulse for reactive power
VAh/I	Volt-Ampere hours per pulse for apparent power

Pulse source

It is possible to select from four different types of pulse sources and operating procedure:


Type	Details
SC	<p>With scanning head</p> <p>The pulses from the scanning head are transferred 1:1 to the reference meter.</p>
SC MAN	<p>Without scanning head</p> <p>An external manual pushbutton is used to trigger the start and stop signals for the measurement.</p> <p>In this method, the user counts the pulses/revolutions and presses the external pushbutton according to the count.</p>
SC1000	<p>F OUT from another reference meter</p> <p>Additional 1000:1 pulse step-down ratio. The pulses from another pulse source are transferred in the ratio 1000:1 to the reference meter.</p> <p>The divisor (1000) is used by the internal software, i.e. the constant can be entered directly and the number of pulses must be divisible by 1000 and have a minimum value of 1000.</p>
St/St	<p>Without scanning head</p> <p>In this method, the user counts the pulses/revolutions and presses the following function keys on the reference meter to start and stop the measurement:</p> <ul style="list-style-type: none"> • Start (to start) • Stop (to stop)

W-register test (energy register)

Description

The 'W-Registertest' function tests the energy register of a meter. The energy register contains the total amount of energy consumed over time. This test finds the difference between the initial value in the energy register at the start time and the final value at the stop time. The difference equals the energy metered by the device under test. The percentage error is calculated by comparing this energy with the energy measured by the reference meter.

Display



Description of parameters

Parameter	Details
Beg.:	Value entered as the initial value from the energy register
End:	<ul style="list-style-type: none"> Value entered as the final value from the energy register Selected units (μWh ... MWh)
E:	Measured energy in selected units
F:	Energy register error in %

Subfunctions

The 'W-Registertest' function contains the following subfunctions:


Function	Details
	<ul style="list-style-type: none"> Input the initial value from the energy register Select the units (μWh ... MWh)
	<ul style="list-style-type: none"> Input the final value from the energy register Select the units (μWh ... MWh)
	See <i>Save Data subfunction</i> on page 84

P-register test (power register)

Description

The 'P-Registertest' function tests the power register of a meter. A power register contains the peak value of the power that occurred in a measured time period. The P-register test compares the value metered by the device under test (final value) with the value measured independently by the reference meter, and calculates the error from the difference.

Display



Description of parameters

Parameter	Details
Time:	Selected measurement period in minutes, and status of the automatic timer
Beg.:	Value entered as the initial value from the power register The initial value is needed in order to identify whether a peak value (final value) of power was retrieved during the measurement that was higher than the initial value.
End:	<ul style="list-style-type: none"> Value entered as the final value from the power register The final value must be greater than the initial value for the reference meter to obtain a relevant comparison value. Selected units (μW ... MW)
Remain. time (min):	Time remaining for the measurement in minutes
P	Measured power in selected units
F	Power register error in %

Subfunctions

The 'P-Registertest' function contains the following subfunctions:


Function	Details
	<ul style="list-style-type: none"> Input the measurement period Actuate the automatic timer
	<ul style="list-style-type: none"> Input the initial value from the power register Select the units (μW ... MW)
	<ul style="list-style-type: none"> Input the final value from the power register Select the units (μW ... MW)
	See <i>Save Data subfunction</i> on page 84

Selective – optional

Description

The 'Selective' function displays the active, reactive and apparent power for the first 40 harmonics of a selected phase. The sign in front of a measured value indicates whether the power is being drawn from the mains or fed into the mains.

Display



Description of parameters

Parameter	Details
CH	Selected line
N	Display shows the measurements for the first 10 harmonics
P [(k)W]	Active power [units]
Q [(k)var]	Reactive power [units]
S [(k)VA]	Apparent power [units]

Subfunctions

The 'Selective' function contains the following subfunctions:

Function	Details
	Phase selection: L1, L2, L3
	Show the next 10 harmonics: 0...10→10...20→20...30→30...40→0...10→...
	See <i>Save Data subfunction</i> on page 84

MT30 – The functions of the reference meter

Saved Data

Description

The 'Saved Data' subfunction displays in the reference meter the saved measurement data and the relevant settings in the reference meter associated with this data.

Display

05.01.2018 12:00		UR:	IR:	
Saved Data		250 V	C100 A	4WA
No.:	1 of 3	++ -- VIEW DEL		
ID:	3E3			
Rem.:	ZERA-METER-PANEL			
Adr.:	GERMANY			
Type:	W-Registertest			
Date:	05.01.2018 11:50:00			
Range:	U=250 V / I=65 A / 4WA			
U-Rat:	1 V --> 1 V			
I-Rat:	1 A --> 1 A			
Func.		IR	MM	Delete

Description of the display

Parameter	Details
No.:	Data record number
ID:	Customer ID
Rem.:	Comment
Adr.:	Address
Type:	Function used to perform the test, e.g. error measurement
Date:	Date of the measurement
Range:	Measurement ranges and mode
U-Rat:	Voltage transformer ratio
I-Rat:	Current transformer ratio

Subfunctions

The 'Saved Data' function contains the following subfunctions:

Function	Details
++	Display the next data record
--	Display the previous data record
VIEW	View details of the selected data record
DEL	Delete the currently viewed data record

MT30 – The functions of the reference meter

The horizontal function bar

The horizontal function bar differs from the standard function key layout by including the following function key:

Function	Details
Delete	Delete all the data records

Detailed view

The Detailed view for a measurement corresponds to the view for the function in which the data was saved. The data in the screenshot below was saved in the 'Error measurement' function.

05.01.2018 12:00

UR: 250 V IR: C100 A 4WA

Saved Data

Constant: 10000 x 1 I/kWh

Pulses: SC x 500 1

Status

E: 1.50 Wh

F: 00.83 %

Back

MT30 – The functions of the reference meter





Source (ext.) - optional

Description The 'Source (ext.)' function controls an external ZERA source. When an external source is connected, the 'Source (ext.)' function can be used to define and actuate the load point required for the device under test. The operator can set the value for the current and phase angle or power factor for each phase.

Requirement The following requirements must be met:


- An external ZERA source is connected to the reference meter.
- The source and reference meter are connected by an RS232 cable.

Subfunctions The 'Source (ext.)' function contains the following subfunctions:

Function	Details
	Options: Sym or Freq Symmetrically or Frequency is selected under cursor control. Additional selections/entries are then made. Sym: <ul style="list-style-type: none"> • Symmetrically <ul style="list-style-type: none"> • Angle • PF (Power factor) • Not symmetrically <ul style="list-style-type: none"> • Angle Freq: <ul style="list-style-type: none"> • Synchronously • Variable <ul style="list-style-type: none"> • Enter the frequency
	Enter voltage and current of the source
	Activate individual phases of the source
	Open the subfunction for loading or saving the load point

Display showing the set load point

The screen contents will vary depending on the settings for the symmetry of the mains supply.



05.01.2018 12:00 UR: 250 V IR: C100 A 4WA

Source (ext.)

Symmetrically Angle

F: Synchronously Hz

	L1	L2	L3	
U:	100	100	100	V
I:	1	1	1	A
∠I:	0	120.00	240.00	°
	0			
U:	On	On	On	
I:	On	On	On	

SYM FREQ

U/I

UI

Storage icon

<1>

Func. MM On Off

MT30 – The functions of the reference meter

Description of input data

Parameter	Details
Symmetrically / Not symmetrically	<p>Symmetrically: Voltage and current can be set for L1 and then are adopted automatically for L2 and L3.</p> <p>The following phase angles apply depending on the standard:</p> <ul style="list-style-type: none"> IEC 387: $\varphi(IL1) = 0^\circ$, $\varphi(IL2) = 120^\circ$, $\varphi(IL3) = 240^\circ$ DIN 410: $\varphi(UL1) = 0^\circ$, $\varphi(UL2) = 240^\circ$, $\varphi(UL3) = 120^\circ$ <p>Not symmetrically: Voltage, current and phase angle for the voltage and current can be set as required for each phase.</p>
Angle / PF	<p>Choice of 'Angle' or 'PF' (power factor)</p> <p>Angle: <ul style="list-style-type: none"> The phase angle for the voltage (IEC 387) or for the current (DIN 410) can be set for L1 and adopted automatically for L2 and L3. </p> <p>PF: <ul style="list-style-type: none"> The same power factor can be set for L1 - L3. The power factor defines the phase angle. </p>
F:	<p>Select the frequency:</p> <ul style="list-style-type: none"> Synchronously: the frequency cannot be entered Variable: a frequency can be entered: 45–65 Hz
U:	Enter the voltage for each phase
I:	Enter the current for each phase
$\angle I \angle U$ / P/Q:	<ul style="list-style-type: none"> Enter the phase angle <ul style="list-style-type: none"> $\angle I$ for IEC 387 $\angle U$ for DIN 410 P/Q: Input and settings for the power factor and the quadrant
U:	Activation status of the voltage for each phase
I:	Activation status of the current for each phase
<#> (bottom right)	Number for the loaded load point

Display for the subfunction for loading or saving the load point

05.01.2018 12:00

UR: 250 V
IR: C100 A
4WA

Source (ext.)

Pos.: 1

Loadp.: 240 / 240 / 240 V
0 / 240.00 / 120.00 °
5 / 5 / 5 A
0 / 240.00 / 120.00 °
U1, U2, U3, I1, I2, I3

New: 240 / 240 / 240 V
30 / 270.00 / 150.00 °
5 / 5 / 5 A
0 / 240.00 / 120.00 °
U1, U2, U3, I1, I2, I3

<1>

Func.
Load
Save
Back




MT30 – The functions of the reference meter

Description of the display

Parameter	Details
Pos.:	No. of the saved load point
Loadp.:	Data for the selected load point (empty if a load point has not been saved)
New:	Currently set data for the load point
<#>	No. of the saved load point

Subfunctions for loading or saving the load point

The 'Save data' subfunction contains the following subfunctions:

Function	Details
	Display the next saved load point
	Display the previous saved load point
	Delete the saved load point displayed for 'Loadp.:'

Horizontal function bar

The horizontal function bar differs from the standard function key layout by including the following function keys:

Function	Details
Load	The load point displayed for 'Loadp.: ' is set Back to the 'Source (ext.)' function
Save	The load point displayed for 'New:' is saved as the load point
Back	Back to the 'Source (ext.)' function without loading or saving

MT30 – The functions of the reference meter


Dosage (ext.) – optional

Description The 'Dosage (ext.)' function controls the amount (or "dose") of energy supplied from an external ZERA source. The 'Dosage (ext.)' function can be used with a ZERA MT400/500 source to supply a specified amount of energy to the device under test.

Requirement The following requirements must be met:

- An external ZERA source is connected to the reference meter.
- The source and reference meter are connected by an RS232 cable.
- The source and reference meter are connected by a BNC cable.

Display





What data is entered and displayed

Parameter	Details
Dosage mode:	Status of dosage mode
Dosage energy:	Value and units of the dosage energy
E:	Shows the amount of energy still to be supplied after starting the dosage function.

Subfunctions

The 'Dosage (ext.)' function contains the following subfunctions:

Function	Details
	Disable/Enable dosage mode: <ul style="list-style-type: none"> • 'On': enables dosage mode • 'Off': disables dosage mode
	Enter the dosage energy: amount and units.

MT30 – The functions of the reference meter

Dosage procedure

The dosage process is performed in the following stages:

Stage	Procedure
1	On dosage mode being enabled, the external source cuts off the supply of current.
2	When the dosage function is started, the external source switches on the current.
3	The external source supplies current until the specified amount of dosage energy is reached.
4	Once the specified amount of dosage energy is reached, the external source cuts off the supply of current again.

Closing dosage mode


Dosage mode must be set to 'Off' again at the end of the dosage function. If dosage mode is left enabled, this can cause malfunctions.

Settings

Description




The 'Settings' function is used for specifying global settings that apply to all the measurements. The settings must always be made before the actual measurement.

Display



Subfunctions

The 'Settings' function contains the following subfunctions:

Function	Details
	Select the system language Languages available: German, English, Italian, French, Czech, Spanish, Turkish, Serbian, Hungarian
	Select the phase angle calculation under the 'Norm' entry Choice of IEC 387 or DIN 410
	Select the mode for controlling the source and dosage of the reference meter <ul style="list-style-type: none"> • Device • Dual • External

Meaning of the 'Norm' selection for the phase angle calculation

The choice made under the 'Norm' entry affects how values are displayed:

Options	Details
IEC 387	<ul style="list-style-type: none"> • Current vectors are fixed, voltage vectors are variable • Reference value I_1, displayed horizontally • $\varphi(I_1)$ is always 0 (in 3 O'clock position) • Positive angle is anticlockwise
DIN 410	<ul style="list-style-type: none"> • Voltage vectors are fixed, current vectors are variable • Reference value U_1, displayed vertically • $\varphi(U_1)$ is always 0 (in 12 O'clock position) • Positive angle is clockwise

MT30 – The functions of the reference meter

What the input data means for the Control function

An external instrument connected to the reference meter via the RS232 port can be used to control the reference meter. The list box contains the following options:

Input	Details
Device	<ul style="list-style-type: none">• Control is via the reference meter's built-in keypad• The external instrument is not used for control purposes
Dual	<ul style="list-style-type: none">• Control is via the reference meter's built-in keypad• The external instrument is also used for control
External	<ul style="list-style-type: none">• Control is not possible via the reference meter's built-in keypad• Only the external instrument is used for control

Settings (2)




Description

The 'Settings (2)' function is used for specifying additional global settings that apply to all the measurements. The settings must always be made before the actual measurement.

Display

Subfunctions

The 'Settings (2)' function contains the following subfunctions:


Function	Details
	Enter the system time in the format dd.mm.yyyy hh:mm:ss
	Select the method for calculating the apparent power for each separate phase (S) and as a total value (ΣS) <ul style="list-style-type: none"> • Arithmetical $S_{\Sigma} = U_1 \cdot I_1 + U_2 \cdot I_2 + U_3 \cdot I_3$ • Geometrical $S_{\Sigma} = \sqrt{P_{\Sigma}^2 + Q_{\Sigma}^2}$
	Optional function: Select a connected thermal printer: <ul style="list-style-type: none"> • Seiko • Mobile Pro

Ratio

Description

The 'Ratio' function is used for entering the transformer ratios of any current and voltage transformers that may be connected on the input side of the meter. These ratios can then be taken into account to provide the correct measured values. The values for the transformer ratios must always be entered before the actual measurement.

Display



Subfunctions

The 'Ratio' function contains the following subfunctions:

Function	Details
	Enable the input of all the rated voltages and currents, starting with the rated primary voltage (pressing the Enter key takes you to the next input option)
	Disable/Enable the ratio for the meter constant: <ul style="list-style-type: none"> • 'On': enable • 'Off': disable
	Enter the rated-current ratio for external high-current transformers (HCT) in AC current clamps (the ratio is obtained by dividing the value entered for the primary rated current by the value entered for the secondary rated current of the HCT) <p>NOTICE! Because no other external current clamps can be connected to this device, the operator must ensure that the values set here are always set 1:1.</p>
	Select the conversion for the actual values. <ul style="list-style-type: none"> • U/I: Select this option for measurement using current or voltage transformers • Off: Select this option for a measurement without current or voltage transformers (measurement directly at the meter) • HCT: This function is not supported by the MT30.

MT30 – The functions of the reference meter

Ratio for voltage and current transformer

In many meter installations, transformers are used to step down the large voltage and current values. The measurement must take into account the ratios for the transformers depending on the position of the taps.

For voltage transformers it is also necessary to enter a factor for the primary and secondary sides of the transformer. There is a choice of two values:

Factor	Usage
x1	for two-pole voltage transformers in a three-phase, 3-wire meter installation, where the voltage value represents the voltage from phase to phase e.g. 11 kV
$1/\sqrt{3}$	for single-pole voltage transformers in a three-phase, 4-wire meter installation, where the voltage value represents the voltage from phase to phase e.g. $11 \text{ kV}/\sqrt{3}$

The Save Data subfunction

Description

The 'Save Data' subfunction can be used to save the currently measured data for the selected function. The 'Save Data' subfunction is available in most functions.

If the Print function is available (optional), the currently measured data for the selected function can be printed.




Display

Description of the display

Parameter	Details
ID:	Customer ID
Rem.:	Comment
Adr.:	Address
Used:	Percentage of memory space used
Free:	Percentage of memory space available

Subfunctions

The 'Save data' subfunction contains the following subfunctions:

Function	Details
	Enter customer ID • 25 characters maximum
	Enter comment • 25 characters maximum
	Enter address • 25 characters maximum

MT30 – The functions of the reference meter

Horizontal function bar

The horizontal function bar differs from the standard function key layout by including the following function keys:

Function	Details
Print (optional)	Print the currently measured data including the customer information
Save	Save the data record <ul style="list-style-type: none"> • Updates the percentages for used and available memory space
Back	Return to the function without saving the data record

Information on printing

The data that is printed is always the data for the function from which 'Save data' was opened.

Requirements:

- The 'Print' option is available.
- A suitable printer is connected to the RS-232 port.
- The printer is configured; see *Settings(2)* on page 81

Information on saving

- If several sets of data need to be saved under the same customer ID, there is no need to re-enter the address and comments.
- A PC running the relevant software can be used to access the data held in the memory. It is also possible, for instance, to reprint a vector diagram from the saved values.

Memory usage

- Total memory space: 250 kB
- Approximate memory usage per save operation for one data record for the functions:
 - Actual Values, Vector, Harmonics, Error Measurement, P-Register test, W-Register test: 0.2 % of the total memory space
 - Waveforms: 1.6 % of the total memory space

Calculation of derived values

Voltage, current and measurement periods are measured, but all other variables are calculated and are therefore derived values. In all formulae, an L as subscript stands for the line, where L is a member of the set {L1; L2; L3}. If the turns ratio for voltage or current is not 1:1, the given formulae must be corrected accordingly.

Contents

In this Chapter

Page

Calculating the voltage	87
Calculating the current	88
Power for the 4-wire measurement	89
Power for the three-phase 3-wire measurement	90
Phase angles	91
Accuracy test	92

Calculating the voltage

Effective value of the voltage

$$U_L = \sqrt{\frac{1}{N} \sum_{n=1}^N U_{L;n}^2}$$

U_L Effective value of the voltage between line L and neutral

$U_{L;n}$ Sampled value of the voltage between line L and neutral

N Number of samples

Voltage harmonic

$$U_k = \sqrt{a_{U_k}^2 + b_{U_k}^2}$$

$$U_k \% = \frac{U_k}{U_1} \cdot 100 \%$$

where

$$a_{U_k} = \frac{2}{N} \sum_{n=0}^{N-1} U_n \cos\left(k \frac{2\pi n}{N}\right)$$

$$b_{U_k} = \frac{2}{N} \sum_{n=0}^{N-1} U_n \sin\left(k \frac{2\pi n}{N}\right)$$

k Number of the harmonic

U_k Effective value of the kth voltage harmonic

$U_k\%$ Ratio of U_k to U_1 in %

U_1 Effective value of the voltage fundamental

a_{U_k} Real part of U_k

b_{U_k} Imaginary part of U_k

Total harmonic distortion (THD) of the voltage

$$\text{THD}(U_L)\% = \frac{\sqrt{\sum_{k=2}^{40} U_{L;k}^2}}{U_{L;1}}$$

$\text{THD}(U_L)\%$ Total harmonic distortion (THD) of the voltage in %

Distortion factor (THD_R) of the voltage

$$\text{THD}_R(U_L)\% = \frac{\sqrt{\sum_{k=2}^{40} U_{L;k}^2}}{U_L}$$

$\text{THD}_R(U_L)\%$ Distortion factor (THD_R) of the voltage in %

MT30 – Calculation of derived values

Calculating the current

Effective value of the current

$$I_L = \sqrt{\frac{1}{N} \sum_{n=1}^N I_{L;n}^2}$$

I_L Effective value of the current in line L
 $I_{L;n}$ Sampled value of the current in line L
 N Number of samples

Current harmonic

$$I_k = \sqrt{a_{I_k}^2 + b_{I_k}^2}$$

$$I_k \% = \frac{I_k}{I_1} \cdot 100 \%$$

where

$$a_{I_k} = \frac{2}{N} \sum_{n=0}^{N-1} I_n \cos\left(k \frac{2\pi n}{N}\right)$$

$$b_{I_k} = \frac{2}{N} \sum_{n=0}^{N-1} I_n \sin\left(k \frac{2\pi n}{N}\right)$$

k Number of the harmonic
 I_k Effective value of the kth current harmonic
 $I_k \%$ Ratio of I_k to I_1 in %
 I_1 Effective value of the fundamental of the current
 a_{I_k} Real part of I_k
 b_{I_k} Imaginary part of I_k

Total harmonic distortion (THD) of the current

$$\text{THD}(I_L) \% = \frac{\sqrt{\sum_{k=2}^{40} I_{L;k}^2}}{I_{L;1}}$$

$\text{THD}(I_L) \%$ Total harmonic distortion (THD) of the current in %

Distortion factor (THD_R) of the current

$$\text{THD}_R(I_L) \% = \frac{\sqrt{\sum_{k=2}^{40} I_{L;k}^2}}{I_L}$$

$\text{THD}_R(I_L) \%$ Distortion factor (THD_R) of the current in %

Power for the 4-wire measurement

Active power

$$P_L = \sqrt{\frac{1}{N} \sum_{n=1}^N u_{L;n}^2 \cdot i_{L;n}^2}$$

P_L Active power for line L

$u_{L;n}$ Sampled value of the line-neutral voltage for line L

$i_{L;n}$ Sampled value of the current in line L

N Number of samples in a period (1/f)

Reactive power

$$Q_L = \frac{1}{N} \sum_{n=1}^N u_{L;n}^2 \cdot i_{L;n-N/4}^2$$

Q_L Reactive power for line L

$u_{L;n}$ Sampled value of the phase-neutral voltage for the line L

$i_{L;n-N/4}$ Sampled value of the current in line L, 1/4 period ahead of the voltage

N Number of samples in a period (1/f)

Apparent power

In geometric mode:

$$S_L = \sqrt{P_L^2 + Q_L^2}$$

In arithmetic mode:

$$S_L = U_L \cdot I_L$$

S_L Apparent power for line L

Power factor λ

$$\lambda_L = \frac{P_L}{Q_L}$$

λ_L Power factor for phase L;

for sinusoidal variables, equals the active power factor $\cos \varphi$

Active power factor $\cos \varphi$

Only applies to function tests in the 4-wire active mode (4WA)

Only applicable with sinusoidal variables: $\text{THD}_R(I_L)$; $\text{THD}_R(I_L) \approx 1$

Total powers P_Σ , Q_Σ , S_Σ

$$P_\Sigma = P_{L1} + P_{L2} + P_{L3}$$

P_Σ Total active power

$$Q_\Sigma = Q_{L1} + Q_{L2} + Q_{L3}$$

Q_Σ Total reactive power

S_Σ Total apparent power

In geometric mode:

$$S_\Sigma = \sqrt{P_\Sigma^2 + Q_\Sigma^2}$$

In arithmetic mode:

$$S_\Sigma = U_1 \cdot I_1 + U_2 \cdot I_2 + U_3 \cdot I_3$$

Power for the three-phase 3-wire measurement

Active power

$$P_2 = U_{L32} \cdot I_{L3} \cdot \cos(\angle U_{L32} - \angle I_{L3})$$

$$P_1 = U_{L12} \cdot I_{L1} \cdot \cos(\angle U_{L12} - \angle I_{L1})$$

$P_1; P_2$ Active powers

U_{L32} Effective value of the voltage between lines L3 and L2

U_{L12} ... L1 and L2

$I_{L1}; I_{L3}$ Effective value of the currents in the outside lines L1 and L3 respectively

Reactive power (true)

$$Q_1 = U_{L12} \cdot I_{L1} \cdot \sin(\angle U_{L12} - \angle I_{L1})$$

$$Q_2 = U_{L32} \cdot I_{L3} \cdot \sin(\angle U_{L32} - \angle I_{L3})$$

$Q_1; Q_2$ reactive powers

U_{L32} Effective value of the voltage between lines L3 and L2

U_{L12} ... L1 and L2

$I_{L1}; I_{L3}$ Effective value of the currents in the outside lines L1 and L3 respectively

Total powers $P_\Sigma, Q_\Sigma, S_\Sigma$

$$P_\Sigma = P_1 + P_2$$

$$Q_\Sigma = Q_1 + Q_2$$

In geometric mode:

$$S_\Sigma = \sqrt{P_\Sigma^2 + Q_\Sigma^2}$$

P_Σ Total active power

Q_Σ Total reactive power

S_Σ Total apparent power (always geometric)

Phase angles

Phase angle of the voltage

$$\angle U_L = \arctan \left(\frac{b_{U_{1:L}}}{a_{U_{1:L}}} \right) - \varphi_{\text{Ref}}$$

- $\angle U_L$ Phase angle of the fundamental voltage harmonic in line L referred to the reference channel
- φ_{Ref} Phase angle of the reference channel (DIN410: U1; IEC387: I1)
- $a_{U_{1:L}}$ Real part (active component) of the 1st voltage harmonic in line L
- $b_{U_{1:L}}$ Imaginary part (reactive component) of the 1st voltage harmonic in line L

Phase angle of the current

$$\angle I_L = \arctan \left(\frac{b_{I_{1:L}}}{a_{I_{1:L}}} \right) - \varphi_{\text{Ref}}$$

- $\angle I_L$ Phase angle of the fundamental current harmonic in line L referred to the reference channel
- φ_{Ref} Phase angle of the reference channel (DIN410: U1; IEC387: I1)
- $a_{I_{1:L}}$ Real part (active component) of the 1st current harmonic in line L
- $b_{I_{1:L}}$ Imaginary part (reactive component) of the 1st current harmonic in line L

Accuracy test

Accuracy test

$$F\% = \frac{N_{\text{must}} - N_{\text{actual}}}{N_{\text{actual}}} \cdot 100\%$$

where

$$N_{\text{must}} = \frac{3600 \frac{\text{s}}{\text{h}} \cdot 1000 \frac{\text{W}}{\text{kW}} \cdot n \cdot C_{\text{PZ}}}{U_{\text{B}} \cdot I_{\text{B}} \cdot C}$$

$F\%$ Error (measurement deviation) in %

N_{must} Number of pulses calculated by the reference meter that must be received from the DUT

N_{actual} Actual number of pulses received from the DUT

n Number of cycles ($n + 1 =$ number of measurement cycles)

U_{B} Voltage measurement range

I_{B} Current measurement range

C_{PZ} Reference frequency at 100% P (Q) in Hz

C Meter constant or pulse constant [$\text{kWh}^{-1} / \text{kvarh}^{-1}$]

Meter constant

The reference meter has a power-proportional output frequency of 60000 Hz in each nominal voltage and current measurement range.

Formula for converting the output frequency into pulses per kilowatt-hour.

$$C \left[\frac{\text{Imp}}{\text{kWh}} \right] = \frac{1000 \cdot 3600 \cdot 60000 \frac{\text{Imp}}{\text{s}}}{n \cdot U_{\text{B}} \cdot I_{\text{B}}}$$

n Number of lines ($n \in \{1; 3\}$)

U_{B} Voltage measurement range

I_{B} Current measurement range

Value table for C for $n = 3$ and $U_{\text{B}} = 250 \text{ V}$:

I_{B} [A]	C [Imp/kWh]
100	2880000
50	5760000
10	28800000
5	57600000
1	288000000
0.5	576000000

Troubleshooting and routine maintenance

Contents

In this Chapter

Page

Cleaning and routine maintenance	94
Battery use	95
Potential problems arising from the hardware	96
Potential problems arising from use	97
Warranty, Service, Disposal	99

Cleaning and routine maintenance

Frequency of cleaning and maintenance	There are no set intervals for cleaning and maintenance. The usage determines how often cleaning and maintenance is carried out.
Cleaning the reference meter	Use a soft, slightly damp cloth to clean the instrument. Never use abrasive cleaners, solvents or alcohol for cleaning. These may damage the equipment or remove its labelling.
Cleaning the cables	The cables must be cleaned regularly because dirt can affect or reduce the insulating properties/insulation. This may cause electric shock or a short-circuit in wet or damp environments. Always inspect the cables for signs of damage. Damaged cables must be replaced.
Cleaning and maintaining the AC current clamps	The clamps of the AC current clamps must be cleaned regularly with a soft cotton cloth using a corrosion inhibitor spray such as CRC 2-26 Check that the clamp jaws meet up. The clamp jaws may get twisted out of shape if the clamps are not handled carefully. This will result in inaccurate measurements. Twisted clamp jaws must be replaced.

Battery use

The batteries If batteries are fitted, the reference meter can be used temporarily without the mains adapter. The power is then supplied by the batteries (3 in all). The batteries are rechargeable lithium-ion batteries (3.7 V / 2200 mAh).

Battery use



Fire and explosion hazard arising from mechanical damage or overheating of the batteries

Mechanical damage can cause short-circuits inside the battery. The resultant current flow can produce heat, which in turn can cause a fire or explosion, which may not even occur until hours after the damage. The same applies to operation above the approved operating temperature.

- Protect the batteries from mechanical damage.
- Do not use the batteries in an environment that is warmer than 60 °C.

Battery lifetime

Batteries only have a limited lifespan. If the reference meter works for less than 30 minutes from a fully charged battery then the batteries are faulty. A faulty battery is also indicated by rapid flashing of the 'Charge' LED.

New batteries can be purchased from ZERA. For ordering information, please see the MT30 product catalogue.

Battery charging

The batteries are charged while the mains adapter is connected. The charge level is indicated by the 'Charge' LED.

LED	Details
Permanently on	Instrument being powered from the mains adapter Internal battery is fully charged
Flashing slowly	Instrument being powered from the mains adapter Internal battery is being charged
Flashing rapidly	Instrument being powered from the mains adapter Internal battery is faulty; must be replaced immediately
Off	Instrument under battery power

Storage

The charge level of lithium ion batteries needs to be checked regularly if they are stored for prolonged periods. The optimum charge level is between 50 % and 80 %. Although the self-discharge rate of 1 % per month is extremely low, it is highly dependent on temperature. Lithium-ion batteries should be recharged every 3 to 4 months to prevent deep discharge. If a cell gets to less than 2 Volts it may be irreparably damaged. Lithium-ion batteries should be stored in as cool a place as possible because of the sharp drop in lifetime associated with an increase in storage temperature.

Potential problems arising from the hardware

Instrument will not run

Cause	Suggested remedy
Instrument has "frozen"	Press the Reset button: the reference meter starts running
No power supply	Check whether the adapter is supplying 16 V. • If not, replace the mains adapter.
Batteries flat or faulty	Connect a power supply • Battery indicator flashing rapidly: batteries faulty • Battery indicator flashing slowly: batteries being charged
Current measurement ranges not displayed	Insert plugs from AC current clamps correctly. • If the current measurement ranges are still not displayed, replace the AC current clamps

No response to the ON/OFF button

Cause	Suggested remedy
ON/OFF button pressed too briefly	Press ON/OFF button for at least 5 secs
Instrument has "frozen"	Press the Reset button: the reference meter starts running

Current measurement ranges not displayed

Cause	Suggested remedy
AC current clamps not plugged in correctly	Screw in place the 25-pin plug for the AC current clamps.
AC current clamps are faulty	Replace the AC current clamps

Incorrect voltage and current measurements

Cause	Suggested remedy
Instrument is no longer calibrated correctly	Run functional test; see Power check

No light on scanning head

Cause	Suggested remedy
Lead is loose or faulty	• Check lead is connected properly • Replace lead
Scanning head is faulty	• Replace scanning head

Potential problems arising from use

Actual values are incorrect or too high

Cause	Suggested remedy
Wrong ratio for voltage/current transformer	<ul style="list-style-type: none"> Enter the correct values in 'Settings' Enable/Disable the ratio for voltage/current transformer in 'Settings 2'

Error measurement reads 99.99 % or HH.HH %

Cause	Suggested remedy
Ratio for voltage/current transformer	<ul style="list-style-type: none"> Enter the correct values in 'Settings' Enable/Disable the ratio for voltage/current transformer in 'Settings 2'
Incorrect meter constant	<ul style="list-style-type: none"> Correct the meter constant under 'Error measurement' Enable/Disable the meter constant in 'Settings 2'
Incorrect measuring mode	<ul style="list-style-type: none"> Set correct mode
Scanning head not adjusted correctly	<ul style="list-style-type: none"> Correct the scanning head

Error measurement taking too long or does not start

Cause	Suggested remedy
Incorrect current measurement range	Set the correct current measurement range
Number of pulses to be counted is too high	Check/correct pulse number and factor
Scanning head not adjusted correctly	Reposition the scanning head correctly

The percentage error is 67 % or 33 %

Cause	Suggested remedy
AC current clamps connected in wrong order	Check test setup <ul style="list-style-type: none"> AC current clamp L1 to L1, L2 to L2, L3 to L3, check direction of current for the AC current clamp
Voltage connection UL1, UL2, UL3, UN mixed up	<ul style="list-style-type: none"> Check test setup
Scanning head not adjusted correctly	<ul style="list-style-type: none"> Check the scanning head

Accuracy for $\cos \varphi = 1$ is OK but not for $\cos \varphi = 0.5$ ind

Cause	Suggested remedy
AC current clamps corroded	<ul style="list-style-type: none"> Clean them
AC current clamps do not close completely	<ul style="list-style-type: none"> Replace the AC current clamps

High error (e.g. 2000 %) in the P-/W-register test

Cause	Suggested remedy
Wrong ratio for voltage/current transformer	<ul style="list-style-type: none"> Enter the correct values in 'Settings' Enable/Disable the ratio for voltage/current transformer in 'Settings 2'

Unable to perform Save operation

Cause	Suggested remedy
Cursor in wrong field	<ul style="list-style-type: none"> Press Enter then press Save
Memory full	<ul style="list-style-type: none"> Clear the memory Back up the data first on a PC if necessary

MT30 – Troubleshooting and routine maintenance

Data download to the PC will not run

Cause	Suggested remedy
RS232 cable not connected properly	<ul style="list-style-type: none"> • Check connection
Wrong interface port selected	<ul style="list-style-type: none"> • Select the correct interface in MTVis software

Data download was stopped

Cause	Suggested remedy
Timeout time in MTVis software is too short	<ul style="list-style-type: none"> • Select a larger value

Data download taking too long

Cause	Suggested remedy
Other entries being made in parallel with the data download	<ul style="list-style-type: none"> • Do not press any buttons during the download

The power from an external source cannot be switched off

Cause	Suggested remedy
Dosage mode is enabled in the Dosage function (ext.).	Set Dosage mode to 'Off'

Warranty, Service, Disposal

Warranty

ZERA guarantees to the customer that any product from ZERA GmbH, Germany is free from defects in materials and/or workmanship for the duration of the warranty period. ZERA GmbH will repair or replace damaged parts that are returned post-paid during the warranty period. Replacement or repair of damaged parts will be free of charge provided there are no signs of misuse or usage other than for its intended purpose. ZERA GmbH does not extend this warranty to damage caused by incorrect or inadequate maintenance or operation by unqualified persons. ZERA GmbH does not extend this warranty to cover costs for routine maintenance or for calibration required by local laws and regulations. ZERA GmbH does not extend this warranty to consumable parts such as rechargeable batteries or other parts subject to wear from frequent use.

ZERA GmbH does not accept liability for any special, direct, indirect, incidental or consequential damages or losses (including loss of data) whether as a result of infringements of the warranty and contractual terms and conditions or on any theory of liability.

This warranty runs for a period of 12 months from the date of installation or for a period of 15 months from the date of dispatch, whichever is earlier.

The ZERA Service

If you need spare parts or have any technical questions, please contact our Service department, making sure you have the following information to hand:

- Equipment serial number
- Equipment order number
- Detailed description of the problem/fault

To contact our Service department:

Tel +49 2244 9277-169
Email service@zera.de

Returns

Should it be necessary to return the instrument to ZERA for servicing or repair work, pack the unit carefully and firmly with suitable packaging and ship it in a well-padded cardboard box to avoid damage. Never return the reference meter in an unsealed or flexible pack. ZERA does not accept liability for any damage arising from improper packing.

Procedure for a Service request

ZERA's website (www.zera.de) includes a Service/Repair area giving precise instructions on how to place a Service request. A special CALL form is provided for this purpose, which you need to download from the website. Then simply follow the guidance on the CALL form.

Disposal – WEEE

During their entire lifetime, the products from ZERA GmbH do not pose a potential hazard to human health or the environment if the following conditions are met:

- product used properly in accordance with intended use
- product disposed of in accordance with WEEE regulations.

ZERA GmbH is registered under WEEE reg. no. DE 53879641. This is required according to EU law for the disposal of waste electrical and electronic equipment.

According to EU law, it is the responsibility of the user to dispose of the product in accordance with WEEE regulations.

Index

∠

∠IU.....	58
∠U.....	58
∠UI.....	58

A

AC current clamps	12, 94
Active power	58, 71
Actual values	53, 58, 97
Apparent power	58, 71, 81
Auto.....	55

B

Bar graph	65
Basic kit.....	12
Battery.....	95
Battery compartment	14
Battery indicator.....	22

C

Cables.....	12, 94
Calculation.....	86
Case.....	12
Computer	17
Connection.....	27
Connection diagrams.....	27, 39, 40, 42, 44, 46, 48, 50
Connection sequence	27
Connection diagrams.....	27, 39, 40, 42, 44, 46, 48, 50
Connection sequence	27
Control buttons	15
CT	17
Current measurement range	22, 23, 55
display	22
select	23
Current transformer	44, 48, 50, 82
Cursor control	15
Curve	53, 64

D

DC IN 16V	17
Declaration of conformity	5
Derived values	86
Disconnection	27
Display area	21
Disposal	99
Distortion factor	58, 65, 87, 88
Dosage (ext.)	53, 77
Dosage energy	77
Dosage mode	77

E

Effective values	58, 88
Energy register test.....	37, 69
Error Measurement.....	32, 34, 53, 67, 92, 97
using scanning head.....	32
without scanning head	34

F

F	58
f OUT	17
Frequency	58
Function	57
Actual values	53, 58, 97
Curve	53, 64
display.....	22
Dosage (ext.)	53, 77
Error Measurement.....	32, 34, 53, 67, 92, 97
Harmonics.....	53, 65
P-Register test	38, 53, 70
Save data.....	84
Saved Data	53, 72
select	23
Selective	53, 71
Settings	53, 79
Settings (2)	53, 81
Source (ext.)	53, 74
Vector.....	53, 61
W-Register test	37, 53, 69
Function bar	52

MT30 – Index

horizontal	21, 23	PC	17
vertical	21, 23	Personal protective equipment	10
Function keys	15	Personnel	10
H		Electrician	10
Harmonics	53, 65	Requirements	10
I		Phase angle	58, 74
I	58	Power	58, 89, 90
Id	58	Power factor	58, 74
L		Power register test	38, 70
LED	17	P-Register test	38, 53, 70
CHARGE	17	Print	84
P (Power)	17	Printer	17, 81
R (Ready)	17	PS	58
Load point	74	Q	
load74		Q	58
save	74	R	
M		ratio	82
Maintenance	93, 94	Reactive power	58, 71, 89, 90
Measurement	27	Reference meter	14
Error Measurement	32, 34, 53, 67, 92, 97	Register test	37, 38
General procedure	27	Reset button	14
preparations	25	Rotating field	58
Measurement ranges	55	RS-232	17
Meter constant	31, 67, 82	S	
Meter types - Connection	39	S	58
Single-phase 2-wire meter	40	Save	84, 97
Three-phase 3-wire	42, 44	Save data	84
Three-phase 4-wire meter	46, 48, 50	Saved Data	53, 72
Mode	22, 56	SC	17
display	22	Scanning head	12, 32
select	23	Scanning-head mount	12, 30
N		Types of scanning head	67
Numeric keypad	15	Screen	15
O		Selecting the language	25, 79
ON/OFF button	15, 96	Selective	53, 71
P		Service	99
P	58	Settings	53, 79
		Settings (2)	53, 81
		Source (ext.)	53, 74

MT30 – Index

Special characters	15
Standard	25, 61
Switching on	25, 96
Symmetrically	74

T

Target readership	6, 9
Technical data	18, 21, 22
Temperature	58
T 58	
THD	65, 88
Troubleshooting	93, 94, 96, 97
Type plate	14

U

Ud	58
UL1	17
UL2	17
UL3	17
UN	17
Upn	58
Upp	58

V

Vector	53, 61
Voltage measuring range	22
display	22
select	23
Voltage transformer	44, 50, 82

W

Warranty	99
WEEE	99
W-Registertest	37, 53, 69

Λ

λ	58
---------	----

Σ

ΣP	58
ΣQ	58
ΣS	58
Σλ	58